

UPC-E Check Character



Transmit UPC-E Check Character (default)



Do not Transmit UPC-E Check Character

Convert UPC-E to UPC-A



Convert UPC-E to UPC-A



Do not Convert UPC-E to UPC-A Off (default)